

## 1.- ORION ITALIA SERIES MODBUS PROTOCOL.

The ORION ITALIA SERIES implement a subset of the AEG Modicon Modbus serial communication standard. Many devices support this protocol directly with suitable interface card, allowing direct connection of relays. The Modbus protocol is hardware-independent; that is, the physical layer can be any of variety of standard hardware configurations, this includes RS232, RS422, RS485, fibber optics, etc. The ORION ITALIA RELAYS include rear terminals that can be RS232 or RS485 ports. Modbus is a single master multiple slave protocol suitable for a multi-drop configuration as provided by RS485 hardware. In this configuration up to 32 slaves can be daisy-chained together on a single communication channel.

The SMPR-1 - ORION ITALIA Relay is always a Modbus slave. It cannot be programmed as a Modbus master. The Modbus protocol exists in two versions: Remote Terminal Unit (RTU, binary) and ASCII. Only the RTU version is supported by the Orion Italia Relay. Monitoring, programming and control functions are possible using read and write register commands.

#### 2.- ELECTRICAL INTERFACE.

The hardware or electrical interface is any of the following:

- a. Two two-wire RS485 for Com2 and Com3 rear terminals connector.
- b. One RS232 for Com1 rear terminal connector.

In a two-wire RS485 link, data flow is bi-directional. RS232 port uses 3-pin Rx for receive data, Tx for Transmit data and signal ground. Different ports Com1, Com2 and Com3 can be used at the same time. Data flow is half duplex. That is, data is never transmitted and received at the same time.

In RS485 lines should be connected in a daisy chain configuration (avoid star connections) with terminating resistors and capacitors installed each end of the link, i.e. at the master end and the slave farthest from the master. That value of the terminating resistors should be equal to the characteristic impedance of the line. This is approximately 120 Ohms for standard 24 AWG twisted pair wire. The value of the capacitors should be 1 nF. Shielded wire should always be used to minimize noise. Polarity is important in RS485 communications. See figure below for more details.

## 3.- DATA FRAME FORMAT AND DATA RATE.

One data frame of an asynchronous transmission to or from a Orion Italia Relay consists of 1 start bit, 8 data bits, not parity and 1 stop bit (8N1). This produces a 10 bit frame. This is important for the correct transmission of the data.

The rear RS485 communication ports of the Orion Italia Relay supports operation at 1200,2400,4800, 9600 and 19200 baud.

#### 4.- DATA PACKET FORMAT.

A complete request/response consists of the following bytes transmitted as separate data frames:

### Master Query Message:

(1 byte)
(1 byte)
(variable number of bytes depending on FUNCTION CODE)
(2 bytes)



#### Slave Response Message:

SLAVE ADDRESS	(1 byte)
FUNCTION CODE	(1 byte)
DATA	(variable number of bytes depending on FUNCTION CODE)
CRC	(2 bytes)

A message is terminated when no data is received for a period of 3½ character transmission times. Consequently, the transmitting device must not allow gaps between bytes larger than this interval (about 3ms at 9600 baud).

**Slave Address:** This is the first byte of every message. This byte represents the user-assigned address of the slave device that is to receive a message sent by the master. Each slave device must be assigned a unique address, and only the addressed slave will respond to a message that starts with its address. In a master query message the SLAVE ADDRESS represents the address of the slave to which the request is being sent. In a slave response message the SLAVE ADDRESS is a confirmation representing the address of the slave that is sending the response. A master query message with a SLAVE ADDRESS of 0 indicates a broadcast command. All slaves on the communication link will take action based on the message, but no one will respond to the master.

*Function Code:* This is the second byte of every message. Modbus defines function codes of 1 to 127. The Orion Italia Relay implements some of this functions. See section 7 for details of the function codes supported by the Orion Italia Relay Series Modbus Protocol. In a master query message the FUNCTIONS CODE tells the slave what action to perform. In a slave response message, if the FUNCTION CODE sent from the slave is the same as the FUNCTION CODE sent from the master then the slave performed the function as requested.

**Data:** This will be a variable number of bytes on the FUNCTION CODE. This may include actual values, setpoints or addresses sent by the master to the slave or by the slave to the master. See section 7 for a description of the Orion-supported functions and the data required for each.

**CRC:** This is a two byte error checking code. CRC is sent LSByte first followed by the MSByte. The RTU version of Modbus includes a two byte CRC-16 (16 bit cyclic redundancy check) with every message. The CRC-16 algorithm essentially treats the entire data stream (data bits only; start, stop and parity ignored) as one continuous binary number. This number is first shifted left 16 bits and then divided by a characteristic polynomial (110000000000101B). The 16 bit remainder of the division is appended to the end of the message, MSByte first. The resulting message including CRC, when divided by the same polynomial at the receiver will give a zero remainder if no transmission errors have occurred. If a Orion Modbus slave device receives a message in which an error is indicated by the CRC-16 calculation, the slave device will not respond to the message. A CRC-16 error indicates that one or more bytes of the message were received incorrectly and thus the entire message should be ignored in order to avoid the slave device performing any incorrect operation. The CRC-16 calculation is an industry standard method used for error detection. An algorithm is included in section 5 CRC-16 algorithm to assist programmers in situations where no standard CRC-16 calculation routines are available.



### 5.- CRC-16 ALGORITHM

Once the following algorithm is completed, the working register "A" will contain the CRC value to be transmitted. Note that this algorithm requires the characteristic polynomial to be reverse bit ordered. The most significant bit of the characteristic polynomial is dropped, since it does not affect the value of the remainder. The following symbols are used in the algorithm:

Symbols:	
>	data transfer
Α	16 bit working register
Alow	low order byte of A
Ahigh	high order byte of A
CRC	16 bit CRC-16 value
i,j	loop counter
(+)	logical EXCLUSIVE-OR operator
Ν	total number of data bytes
Di	i-th data byte (i=0 to N-1)
G	16 bit characteristic polynomial =1010000000000000(binary) with MSbit dropped and bit order reversed
shr(x)	right shit operator (the LSbit of x is shifted into a carry lag, a '0' is shifted into the MSbit of x, all other bits are shifted right one location)

#### Algorithm:

1.	FFFF(hex)> A	
2.	0> i	
3.	0> j	
4.	Di (+) Alow> Alow	
5.	j + 1> j	
6.	shr (A)	
7.	Is there a carry ?	No: go to step 8
		Yes: G (+) A> A and continue
8.	ls j = 8 ?	No: go to 5
		Yes: continue
9.	i + 1> i	
10.	ls i = N ?	No: go to 3
		Yes: continue
11.	A> CRC	

#### 6.- MESSAGE TIMING

Communication message synchronization is maintained by timing constraints. The receiving device must measure the time between the reception of characters. If three and one half character times elapse without a new character or completion of the message, then the communication link must be reset (i.e. all slaves start listening for a new query message from the master). Thus at 1200 baud a delay of greater than  $3.5 \times 1/1200 \times 10 = 29.2$  ms cause the communication link to be reset. At 9600 baud a delay of greater than  $3.5 \times 1/9600 \times 10 = 3.6$  ms will cause the communication link to be reset. Most master query messages will be responded to in less than 50 ms. The maximum time for the Orion Italia Relays to return a slave response message for any function code will never exceed 1 second.



## 7.- SUPPORTED FUNTION CODES

The second byte of every message is the function code. Modbus defines function codes of 01h to 7Fh. The Orion Italia Relay Modbus protocol supports some of these functions, as summarized in Table No. 1

#### TABLE No. 1

FUNCTION CODE	FUNCTION CODE	
MODBUS PROT.	ORION ITALIA	
(HEX)	(HEX)	DEFINITION
03	03	READ SETPOINTS or ACTUAL VALUES
04	04	READ SETPOINTS or ACTUAL VALUES
05	05	EXECUTE OPERATION
06	06	STORE SINGLE SETPOINTS
10	10	STORE MULTIPLES SETPOINTS

Since some programmable logic controllers only support function codes 03h (or 04h) and 10h, most of the above Modbus commands can be performed by reading from or writing to special addresses in the Orion Italia Relay memory map using these function codes.

## 7.1.- FUNCTION CODE 03H or 04H - READ SETPOINTS OR ACTUAL VALUES.

Modbus implementation: Read Holding Registers Orion Italia Relay implementation: Read Actual Values or Setpoint

The Orion Italia Relay implementation of Modbus views "holding registers" as any setpoint or actual values register in the Orion Italia Relay memory map. Registers are 16 (two byte) values transmitted high order byte first. Thus all Orion Italia Relay setpoints and actual values in the memory map are sent as two byte registers. This function code allows the master to read one or more consecutive setpoints or actual values from addressed slave device.

The slave response to these function codes is the slave address, function code, a count of the number of data bytes to follow, the data itself and the CRC. Each data item is sent as a two byte number with the high order byte sent first. The CRC is sent as a two byte number with the low order byte sent first.

## MESSAGE FORMAT EXAMPLE:

Request to read 4 register values starting address 0102h from slave device 1.

Master query message	Exam	iple(hex)
SLAVE ADDRESS	01	query message for slave 01 = 01h
FUNCTION CODE	03	read Setpoints
DATA STARTING ADDRESS-high order	01	data starting at address 0102h
DATA STARTING ADDRESS-low order byte	02	
NUMBER OF REGISTERS-high order byte	00	4 register value = 4 word total
NUMBER OF REGISTER-low order byte	04	
CRC-low order byte	E4	CRC calculated by the master
CRC-high order byte	35	





If the function code or the address of any of the requested data is illegal, the slave will **not** respond the message. Otherwise, the slave will respond as follows:

Slave response message	Example	e (hex)
SLAVE ADDRESS	01	response message from slave 1 = 01h
FUNCTION CODE	03	read Setpoints
BYTE COUNT	08	4 register values = 8 bytes total
DATA #1-high order byte	00	register value in address 0102= 0064h
DATA #1-low order byte	64	
DATA #2-high order byte	00	register value in address 0103=0064h
DATA #2-low order byte	64	
DATA #3-high order byte	03	register value in address 0104=03E8h
DATA #3-low order byte	E8	
DATA #4-high order byte	00	register value in address 0105=0064h
DATA #4-low order byte	64	
CRC-low order byte	40	CRC calculated by the slave
CRC-high order byte	42	

# 7.2.- FUNCTION CODE 05H - EXECUTE OPERATION

Modbus implementation: Force Single Coil Orion Italia Relay implementation : Execute Operation

This function code allows the master to request a SMPR-1 to perform specific command operation. The commands Number Listed in the table 2: Commands; correspond to operations codes for function code 05h.

The Slave Response to this function is to echo the entire master transmission. See Format F23 for Command Operations Codes

## MESSAGE FORMAT EXAMPLE:

Request to Remote Reset SMPR-1 Relay.

Master query message	Example	e(hex)
SLAVE ADDRESS	01	Query message for slave 01 = 01h
FUNCTION CODE	05	Execute Operation
OPERATION CODE-high order	00	Reset Relay Command
OPERATION CODE-low order byte	01	
NUMBER OF REGISTERS-high order byte	FF	Perform Function
NUMBER OF REGISTER-low order byte	00	
CRC-low order byte	DD	CRC calculated by the master
CRC-high order byte	FA	
Slave response message	Example	e (hex)
SLAVE ADDRESS	01	Message from slave 01 = 01h
FUNCTION CODE	05	Execute Operation
DATA STARTING ADDRESS-high order	00	Reset Relay Command
DATA STARTING ADDRESS-low order byte	01	
NUMBER OF REGISTERS-high order byte	FF	Perform Function
NUMBER OF REGISTER-low order byte	00	
CRC-low order byte	DD	CRC calculated by theSlave
CRC-high order byte	FA	



# 7.3.- FUNCTION CODE 06H - STORE SINGLE SETPOINTS

Modbus implementation: Preset Single Register Orion Italia Relay implementation : Store Single Setpoints

This function code allows the master to store single setpoints into the memory map of the SMPR-1. The Slave Response to this function is to echo the entire master transmission.

MESSAGE FORMAT EXAMPLE: Request slave device 01h to write the value 0190h at setpoint address 0102h

Master query message	Exam	iple(hex)
SLAVE ADDRESS	01	query message for slave 01 = 01h
FUNCTION CODE	06	Store Single Setpoints
DATA STARTING ADDRESS-high order	01	Setpoint Address 0102h
DATA STARTING ADDRESS-low order byte	02	
NUMBER OF REGISTERS-high order byte	01	Data for Address 0102h = 0190h
NUMBER OF REGISTER-low order byte	90	
CRC-low order byte	28	CRC calculated by the master
CRC-high order byte	0A	

Slave response message	Example	e (hex)
SLAVE ADDRESS	01	Message from slave 01 = 01h
FUNCTION CODE	06	Store Single Setpoints
DATA STARTING ADDRESS-high order	01	Setpoint Address 0102h
DATA STARTING ADDRESS-low order byte	02	
NUMBER OF REGISTERS-high order byte	01	Data Stored in Address 0102h = 0190h
NUMBER OF REGISTER-low order byte	90	
CRC-low order byte	28	CRC calculated by the Slave
CRC-high order byte	0A	

# 7.4.- FUNCTION CODE 10H -STORE MULTIPLE SETPOINTS

Modbus implementation: Preset Multiple Register Orion Italia Relay implementation : Store Multiple Setpoints

This function code allows the master to modify the contest of a one or more consecutive setpoint in the addressed slave device. Setpoint registers are 16 bit (two byte) values transmitted high order byte first. The SMPR-1 Setpoint data starts at address 0100h.

To store the value of one or more setpoints in the internal memory of the SMPR-1, the following steps shall be realized:

a) First shall be read setpoint group to modify with function 03h or 04h.



b) Then, modify the values of setpoints according to memory map.

c) Send setpoint group back to relay with function 10h.

The SMPR-1 response to this function code is to echo the slave address, function code, starting address, the number of setpoints stored, and the CRC.

MESSAGE FORMAT AND EXAMPLE:

Request slave device 11h to write the value 0190h at setpoint address 0102h, and the value 012Ch at setpoint address 0103h.

Master query message	Example (hex)
SLAVE ADDRESS	11 query for slave 11h
FUNCTION CODE	10 store multiple setpoint values
DATA STARTING ADDRESS-high order byte	01 data starting at address 0102
DATA STARTING ADDRESS-low order byte	02
NUMBER OF SETPOINTS-high order byte	00 2 setpoint values = 2 word
NUMBER OF SETPOINTS-low order byte	02
BYTE COUNT	04 4 byte of data
DATA #1-high order byte	01 data for address 0102h=012Ch
DATA #1-low order byte	2C
DATA #2-high order byte	01 data for address 0103h=012Ch
DATA #2-low order byte	2C
CRC-low order byte	9E CRC calculated by the master
CRC-high order byte	46

If the function code or the address or value of any of the data, is illegal, the slave will not respond to the message. Otherwise, the slave will respond as follows:

Master query message	Example (hex)
SLAVE ADDRESS	11 Message from slave 11h
FUNCTION CODE	10 store multiple setpoint values
DATA STARTING ADDRESS-high order byte	01 data starting at address 0102h
DATA STARTING ADDRESS-low order byte	02
NUMBER OF SETPOINTS-high order byte	00 2 setpoint values = 2 word
NUMBER OF SETPOINTS-low order byte	02
CRC-low order byte	E1 CRC calculated by the slave
CRC-high order byte	5E

## 8.- MEMORY MAP INFORMATION

The data stored in the SMPR-1 is grouped generally on Setpoints, Actual Values and Product ID. Setpoints can be read and written by a master computer. Actual Values & Product ID are read only. All data is stored as two bytes values (16 bit Word). Addresses are listed in hexadecimal. Data values (Setpoint ranges, increments, factory value) are in decimal.

See Memory Map below.

			SMPR-1 - MODBUS ME	MORY	/IAP				
Add (Hex)	MODBUS REG.	Size	Description	Unit	Range	Step	Initial Value	Format	Read/
	ADD (Dec)		Product ID				Value		Write
0000	300001	1 W	Product Code				22	F2	R
0001	300002	1 W	Version Number				1.02	F2 F6	R
0003	300004	1 W	Product Language				1	F24	R
			Commands						
0080	400129	1 W	Command Operation Code					F23	R/W
			TimeSet						
0090	400145	3 W	Date & Time Preset Data					F8	R/W
			Common Setpoin	ts					
0100	400257	1 W	Access Code		111~999	1	111	F10	R/W
0101	400258	1 W	System Setup Phase CT Rating Primary	BitField A	 5~5000	5	100	F9 F2	R/W R/W
0103	400260	1 W	Ground CT Rating Primary	A	5~5000	5	100	F2	R/W
0104	400261	1 W	VT Nominal Secondary	V KV	55~254 0 10~69 00	1	100	F2 F6	R/W
0106	400263	1 W	Reserved		0.10 00.00	0.01/0.1	10.00	10	R/W
0107	400264	1 W	Reserved Reserved						R/W
0109	400266	1 W	Amps Demand Period	min.	5~60	1	15	F2	R/W
010A	400267	1 W	Power Demand Period	min.	5~60	1	15	F2	R/W
010B 010C	400268	1 W	Reserved						R/W
010D	400270	1 W	Output Relays Config	BitField			0	F11	R/W
010E 010F	400271 400272	1 W	AUX1 Relay Pulse Time	ms	100~2000	100	200	F2 F2	R/W R/W
0110	400273	1 W	AUX2 Relay Pulse Time	ms	100~2000	100	200	F2	R/W
0111	400274	1 W	AUX3 Relay Pulse Time Reserved	ms	100~2000	100	200	F2	R/W
0112	400276	1 W	Reserved						R/W
0114	400277	1 W	Reserved						R/W
0116	400279	1 W	Reserved						R/W
0117	400280	1 W	Reserved						R/W
0118	400281	1 W	Reserved						R/W
011A	400283	1 W	Block Trip Delay	Sec	0.05~1.00	0.01	0.15	F6	R/W
011B 011C	400284 400285	1 W	Opening Breaker Time Reserved	ms	10~500	10	100	F2	R/W R/W
011D	400286	1 W	Reserved						R/W
011E 011F	400287	1 W	Reserved Reserved						R/W
0120	400289	1 W	Digital Inputs Config	BitField			0	F12	R/W
0121	400290	1 W	Input 1 Function		0~9	1	0	F13	R/W
0122	400292	1 W	Input 3 Function		0~9	1	1	F13	R/W
0124	400293	1 W	Reserved						R/W
0125	400294	1 W	Reserved						R/W
0127	400296	1 W	Reserved						R/W
0128	400297	1 W	Reserved						R/W
012A	400299	1 W	Event Recorder Config	BitField				F14	R/W
012B 012C	400300 400301	1 W	Breaker Driscrepancy Relays Breaker Driscrepancy Delay	 ms	0~14 10~2500	2	0	F15 F2	R/W R/W
012D	400302	1 W	Mechanical Operations Relays		0~15	1	0	F15	R/W
012E 012E	400303	1 W	Mechanical Operations Maximum Accumulated Amp Relays		5~9995 0~15	5	3000	F2 F15	R/W
0130	400305	1 W	Accumulated Amp Level	KA	10~5000	1	300	F2	R/W
0131	400306	1 W	Slave Address	 Poud	1~247	1	1	F2	R/W
0132	400307	1 W	Com2 (RS-485) Baud Rate	Baud	0~4	1	3	F17	R/W
0134	400309	1 W	Com3 (RS-485) Baud Rate	Baud	0~4	1	3	F17	R/W
			Actual Values						
0200	300513	3 W	DMP Relay Date & Time					F8	R
0203	300516 300517	1 W	Front Panel Leds Status	BitField BitField				F18 F18	R
0205	300518	1 W	Output Relays Status	BitField				F20	R
0206	300519	1 W	Digital Inputs Status	BitField				F21	R
0207	300520	1 W	Status Flags 2	BitField				F25 F26	R
0209	300522	1 W	Status Flags 3	BitField				F27	R
020A 020B	300523	1 W	Pickup Flags 1 Pickup Flags 2	BitField				F25 F26	R
020C	300525	1 W	Pickup Flags 3	BitField				F27	R
020D 020F	300526 300528	2 W 2 W	Phase A RMS Current Phase B RMS Current	A				F6 F6	R
0211	300530	2 W	Phase C RMS Current	A				F6	R
0213	300532 300534	2 W	Ground RMS Current	A A				F6 F6	R
0217	300536	2 W	Phase AB RMS Voltage	V				F4	R
0219	300538	2 W	Phase BC RMS Voltage	V				F4	R
021B 021D	300540	2 W	Phase AN RMS Voltage	V				F4	R
021F	300544	2 W	Phase BN RMS Voltage	V				F4	R
0221	300546 300548	2 W 2 W	Phase CN RMS Voltage Current Average	V A				F4 F6	R
0225	300550	2 W	Voltage Average	V			1	F4	R
0227	300552	2 W	Reserved						R
0229 022B	300556	2 W	Reserved						R
022D	300558	2 W	Reserved		[	ſ			R

SMPR-1 Relay - Software Versions (1.02) SMPR-1 - MODRUS MEMORY MAP									
Add (Hex)	MODBUS REG.	Size	Description	Unit	Range	Step	Initial	Format	Read/
022F	ADD (Dec) 300560	2 W	3Ø Real Power	KW			Value	F5	Write R
0231	300562 300564	2 W	3Ø Reactive Power	KVAR KVA				F5	R
0235	300566	2 W	Real Power Phase A	KW				F5	R
0237	300568 300570	2 W	Real Power Phase B	KW				F5	R
0235 023B	300572	2 W	Reactive Power Phase A	KVAR				F5	R
023D	300574 300576	2 W	Reactive Power Phase B	KVAR				F5	R
0231	300578	2 W	Aparent Power Phase A	KVAR				F6	R
0243	300580 300582	2 W	Aparent Power Phase B	KVA KVA				F6	R
0243	300584	1 W	3Ø Power Factor					F19	R
0248	300585 300586	1 W	Reserved						R
0249 024A	300587	1 W	Reserved						R
024B	300588	1 W	Frequency Reserved	Hz				F6	R
0240 024D	300590	1 W	Reserved						R
024E	300591	1 W	Reserved						R
0241	300593	1 W	Phase A Current Unbalance	%				F4	R
0251	300594	1 W	Phase B Current Unbalance	%				F4	R
0252	300595	1 W	Reserved	%				F4	R
0254	300597	1 W	Reserved						R
0255	300598	1 W	Reserved						R
0257	300600	1 W	Reserved						R
0258	300601 300602	1 W	Reserved						R
025A	300603	1 W	Reserved						R
025B	300604	1 W	Reserved						R
025C	300606	1 W	Reserved						R
025E	300607	1 W	Phase Sequence					F32	R
025F	300608	2 W	Positive Active Energy Negative Active Energy	KWh				F2 F2	R
0263	300612	2 W	Positive Reactive Energy	KVARh				F2	R
0265	300614 300616	2 W	Negative Reactive Energy	KVARh				F2 F8	R
0267 026A	300619	2 W	Last Current Demand	A				F6	R
026C	300621	2 W	Last Real Power Demand	KW				F5	R
026E	300623	2 W	Max Current Demand	A				F5 F6	R
0272	300627	3 W	Max Current Demand Date & Time					F8	R
0275 0277	300630 300632	2 W 3 W	Max Real Power Demand Max Real Power Date & Time	KW				F5 F8	R
027A	300635	2 W	Max Reactive Power Demand	KVAR				F5	R
027C 027F	300637 300640	3 W	Max Reactive Power Date & Time					F8 F8	R
0282	300643	2 W	Pre-Trip Phase A RMS Current	А				F6	R
0284	300645	2 W	Pre-Trip Phase B RMS Current	A				F6	R
0288	300649	2 W	Pre-Trip Ground RMS Current	A				F6	R
028A	300651	2 W	Pre-Trip Negative Sequence Current	A				F6	R
028C 028E	300653	2 W	Pre-Trip AB RMS Voltage Pre-Trip BC RMS Voltage	A				F2 F2	R
0290	300657	2 W	Pre-Trip CA RMS Voltage	Α				F2	R
0292	300659 300660	1 W	Pre-Trip Frequency Pre-Trip 30 Power Factor	Hz				F6 F19	R
0200	000000							110	I.
			Maintenance Data	1					
02D0 02D1	300721 300722	1 W 1 W	Accumulated Amp on Phase A	 KA				F2 F2	R R
02D2	300723	1 W	Accumulated Amp on Phase B	KA				F2	R
02D3 02D4	300724 300725	1 W	Accumulated Amp on Phase C Phase O/C Trips	KA				F2 F2	R
02D5	300726	1 W	Ground O/C Trips					F2	R
02D6	300727	1 W	Openning Counter					F2	R
			Events						
0600	301537	1 W	Last Event Number					F2	R
0601	301538 401553	3 W	Last Event Clear Date & Time		 1~65535			F8 F2	R R/M
0611	301554	3 W	Selected Event Date & Time					F8	R
0614	301557	2 W	Selected Event Phase A RMS Current	A				F6	R
0618	<u>3</u> 01561	2 W	Selected Event Phase C RMS Current	A				F6	R
061A	301563	2 W	Selected Event Ground RMS Current	A				F6	R
061C 061E	301565 301567	2 W 2 W	Selected Event Negative Sequence Current Selected Event AB RMS Voltage	A				F6 F2	R R
0620	301569	2 W	Selected Event BC RMS Voltage	A				F2	R
0622	301571	2 W	Selected Event CA RMS Voltage	А 4				F2	R
0625	301574	1 W	Selected Event 3Ø Power Factor					F19	R
		_							
1000	404007	1 \//	Protections Setpoints	Group	0~15	1	1	F15	R/\//
1001	404098	1 W	Phase Timed OverCurrent Pickup	%CT	4~300	1	4	F2	R/W
1002	404099	1 W	Phase Timed OverCurrent Curve		0~12	1	1	F16	R/W
1003 1004	404100 404101	1 W 1 W	Phase Timed OverCurrent Curve Multiplier Phase Timed OverCurrent Delay	Sec	0.1~20.0	0.1 0.01/0.1/1	1.0 1.0	F4 F6	R/W R/W
1005	404102	1 W	Reserved					_	R/W
1006 1007	404103 404104	1 W 1 W	Phase Inst. OverCurrent Relays Phase Inst. OverCurrent Pickup	 %CT	0~15 4~1800	1 1/10	1 40	F15 F2	R/W R/W
							-		

	SMPR-1 Relay - Software Versions (1.02) SMPR-1 - MODBUS MEMORY MAP								
Add (Hex)	) MODBUS REG. Size		Description	Unit	Range	Step	Initial	Format	Read/
1008	ADD (Dec) 404105	1 W	Phase Inst. OverCurrent Delay	ms	0~2000	10	Value	F2	R/W
1008	404105	1 W	Reserved	1113	0~2000	10	0	12	R/W
100A	404107	1 W	Neg. Sequence Timed OverCurrent Relays		0~15	1	1	F15	R/W
100B 100C	404108	1 W	Neg. Sequence Timed OverCurrent Pickup	%C1	4~300 0~12	1	4	F2 F16	R/W
100D	404110	1 W	Neg. Sequence Timed OverCurrent Curve Multiplier		0.1~20.0	0.1	1.0	F4	R/W
100E	404111	1 W	Neg. Sequence Timed OverCurrent Delay	Sec	0.05~600	0.01/0.1/1	1.0	F6	R/W
100F 1010	404112	1 W	Reserved						R/W
1011	404114	1 W	Reserved						R/W
1012	404115	1 W	Phase OverCurrent Alarm Relays		0~15	1	0	F15	R/W
1013	404116	1 W	Phase OverCurrent Alarm Delay	Sec	0.05~600	0.01/0.1/1	4	F2 F6	R/W
1015	404118	1 W	Amp Unbalance Relays		0~15	1	0	F15	R/W
1016	404119	1 W	Amp Unbalance Pickup	%	1~99	1	10	F2	R/W
1017	404120	1 W	Phase UnderCurrent Relays		0.05~600	1	0	F15	R/W
1019	404122	1 W	Phase UnderCurrent Pickup	%CT	2~100	1	4	F2	R/W
101A	404123	1 W	Phase UnderCurrent Delay	Sec	0.05~600	0.01/0.1/1	1.0	F6	R/W
101B	404124	1 W	Reserved						R/W
101D	404126	1 W	Reserved						R/W
101E	404127	1 W	Reserved		0.15	4	1	E15	R/W
101F	404128	1 W	Ground Timed OverCurrent Relays	 %CT	0~15 4~300	1	12	F15	R/W
1021	404130	1 W	Ground Timed OverCurrent Curve		0~12	1	1	F16	R/W
1022	404131	1 W	Ground Timed OverCurrent Curve Multiplier		0.1~20.0	0.1	1.0	F4	R/W
1023	404132	1 W	Ground Timed OverCurrent Delay Reserved	Sec	0.05~600	0.01/0.1/1	1.0	F6	R/W
1024	404133	1 W	Ground Inst. OverCurrent Relays		0~15	1	1	F15	R/W
1026	404135	1 W	Ground Inst. OverCurrent Pickup	%CT	4~1800	1/10	120	F2	R/W
1027	404136	1 W	Ground Inst. OverCurrent Delay	ms	0~2000	10	0	F2	R/W
1020	404137	1 W	Ground OverCurrent Alarm Relays		0~15	1	0	F15	R/W
102A	404139	1 W	Ground OverCurrent Alarm Pickup	%CT	4~300	1	12	F2	R/W
102B	404140	1 W	Ground OverCurrent Alarm Delay	Sec	0.05~600	0.01/0.1/1	1.0	F6	R/W
102C	404141	1 W	Reserved						R/W
102E	404143	1 W	Reserved						R/W
102F	404144	1 W	Reserved		0.45		<u>^</u>	545	R/W
1030	404145	1 W	Undervoltage 1 Relays Undervoltage 1 Pickup	 %VT	0~15	1	0 95	F15 F2	R/W R/W
1032	404147	1 W	Undervoltage 1 Dropout	%VT	15~100	1	97	F2	R/W
1033	404148	1 W	Undervoltage 1 Delay	Sec	0.05~600	0.01/0.1/1	1.00	F6	R/W
1034	404149	1 W	Undervoltage 1 Curve Phases for U/V 1 Operation		0~1	1	0	F29 F30	R/W
1035	404150	1 W	Minimun Operation Level for U/V 1	%VT	0~100	1	0	F2	R/W
1037	404152	1 W	Overvoltage 1 Relays		0~15	1	0	F15	R/W
1038	404153	1 W	Overvoltage 1 Pickup	%VT %VT	1~150	1	105	F2	R/W
1039 103A	404154	1 W	Overvoltage 1 Delay	Sec	0.05~600	0.01/0.1/1	1.00	F2 F6	R/W
103B	404156	1 W	Phases for O/V 1 Operation		0~2	1	0	F30	R/W
103C	404157	1 W	Reserved						R/W
103D	404158	1 W	Reserved						R/W
103F	404160	1 W	Reserved						R/W
1040	404161	1 W	Reserved						R/W
1041	404162	1 W	Reserved						R/W
1043	404164	1 W	Reserved						R/W
1044	404165	1 W	Reserved		0.45	4	0	545	R/W
1045	404166	1 W	Phase Reversal Relays Phase Reversal Delay	Sec	0~15	1 0.01/0.1/1	1.00	F15 F6	R/W
1047	404168	1 W	Frequency 1 Relays		0~15	1	0	F15	R/W
1048	404169	1 W	Frequency 1 Mode		0~2	1	0	F31	R/W
1049 104A	404170 404171	1 W	Frequency 1 Pickup	Hz Hz	0.05~9.99	0.01	1.00	+6 F6	R/W
104B	404172	1 W	Frequency 1 Delay	Sec	0.05~600	0.01/0.1/1	1.00	F6	R/W
104C	404173	1 W	Frequency 2 Relays		0~15	1	0	F15	R/W
104D 104F	404174	1 W	Frequency 2 Mode	 Hz	0~2	1	1.00	F31 F6	R/W
104E	404176	1 W	Frequency 2 Dropout	Hz	0.01~5.00	0.01	0.50	F6	R/W
1050	404177	1 W	Frequency 2 Delay	Sec	0.05~600	0.01/0.1/1	1.00	F6	R/W
1051	404178	1 W	Power Factor Leading Relays		$0 \sim 15$	1	-0.80	F15	R/W
1052	404180	1 W	Power Factor Leading Dropout	L	(-0.99)~(+1.00)	0.01	-0.80	F5	R/W
1054	404181	1 W	Power Factor Leading Delay	Sec	0.5 ~ 650.0	0.5	1.0	F6	R/W
1055	404182	1 W	Power Factor Lagging Relays		0~15	1	0	F15	R/W
1050	404183	1 W	Power Factor Lagging Propout		(-0.99)~(+1.00)	0.01	-0.80	F5	R/W
1058	404185	1 W	Power Factor Lagging Delay	Sec	0.5 ~ 650.0	0.5	1.0	F6	R/W
1059	404186	1 W	Reverse Power Relays		0~15	1	0	F15	R/W
105A 105B	404187	1 W	Reverse Power Pickup	Sec	0.01 ~ 650.00	0.01/0.1/1	1.0	гь F6	R/W
105C	404189	1 W	Forward Power Relays		0~15	1	0	F15	R/W
105D	404190	1 W	Forward Power Pickup	MW	0.01 ~ 650.00	0.01/0.1/1	0.10	F6	R/W
105E	404191	1 W	Forward Power Delay	Sec	0.5 ~ 650.0	0.5	1.0	F6	R/W
1060	404193	1 W	Amp Demand Protection Level	A	5~5000	1	100	F2	R/W
1061	404194	1 W	KW Demand Protection Relays		0~15	1	0	F15	R/W
1062	404195	1 W	KW Demand Protection Level	MW	0.01 ~ 650.00	0.01/0.1/1	0.10	F6	R/W
1064	404190	1 W	KVAR Demand Protection Level	 MVAR	0.01 ~ 650.00	0.01/0.1/1	0.10	F 15 F6	R/W

	SMPR-1 DATA FORMATS				
Format Code	Туре	Value	Definition		
F1	Integer		Signed Integer Value		
E0	Integer		Example 125 Saveu as - 125		
F2	integer		Example: 123 saved as 123		
F3	Integer		Signed Integer Value with 1 decimals		
			Example: -1.0 saved as -10		
F4	Integer		Unsigned Integer Value with 1 decimals		
	Interer		Example: 1.0 Saveu as 10		
гэ	Integer		Example: -1.00 saved as -100		
F6	Integer		Unsigned Integer Value with 2 decimals		
			Example: 1.00 saved as 100		
F7	Floating Point		(4 Byte) Floating Point Value		
			The memory layout of 4-byte floating-point numbers is:		
			31 30 23 22 0		
			S Exponent Mantissa		
			$(1) \\ \\ (2) \\ \\ (2) \\ \\ (2) \\ \\ (2) \\ \\ (2) \\ \\ (2) $		
			Zero is represented by 4 bytes of zeros		
			The precision of the float operators $(+, -, *, and /)$ is approximately		
			7 decimal digits.		
F8	Clock		Date & Time Format		
			15 7 6 0		
			Word         Otherwise NOT USED         (00-512) See Events List         TEAR         (00-99)           Ex. 00 = 2000, 01=2001         Ex. 00 = 2000, 01=2001         Ex. 00 = 2000, 01=2001		
			15         14         13         10         9         5         4         0           2nd         Not         HONEL         DAVS         (1-31/30/29/28)         HONEL		
			Word Used M(U-12)H Depending on the Month & Year (00-23)		
			15 10 9 0 3th MINUTES SECONDS		
			Word (00-59) (00:0-593)		
FQ	16 Bits BitMan		System Setup Benister Format		
15	To Dita Ditinap	Bit 0 ~ Bit 1	System Frequency:		
			0 = 50hz, 1 = 60hz VT Connection:		
		Bit 2 ~ Bit 4	0 = Wye-Wye, 1 = Delta-Delta, 2 = Open Delta		
		Bit 5 ~ Bit 7	1 = Residual, 2 = Zero Sequence		
		Bit 8	Not Used		
		Bit 10	Out of Service on AUX3 ?:		
		Di+ 11	0 = No, 1 = Yes LOCKOUT (86) on AUX2 ?:		
		DIL I I	0 = No, 1 = Yes BLOCK TRIP OUT on AUX1 ?:		
		Bit 12	0 = No, 1 = Yes		
		BIL 11 ~ BIT 15			
F10	Integer		Unsigned Integer Access Code Value Register Format		
			Example: 111 saved as 111 (only digits 1~9 accepted, digit 0 is NOT ALLOWED)		
F11	16 Bits BitMap		Outputs Relays Configuration Register Format TRIP Relay Config.:		
		Bit 0 ~ Bit 1	0 = "LATCHED", 1 = "PULSED"		
		Bit 2 ~ Bit 3	0 = "LATCHED", 1 = "PULSED",		
		Bit 4 ~ Bit 5	AUX2 Relay Config.:		
		Bit 6 ~ Bit 7	AUX3 Relay Config.:		
		Bit 8 ~ Bit 15	0 = "LATCHED", 1 = "PULSED", Not Used		
		Dito Ditio			

F12	16 Bits BitMap		Digital Input Configuration Register Format
		Bit 0	INPUT 1 SET ON:
		Dit 0	0 = "CONTACT CLOSED", 1 = "CONTACT OPEN"
		Bit 1	INPUT 2 SET ON:
		DICI	0 = "CONTACT CLOSED", 1 = "CONTACT OPEN"
		Bit 2	INPUT 3 SET ON:
		DICE	0 = "CONTACT CLOSED", 1 = "CONTACT OPEN"
		Bit 3 ~ Bit 15	Not Used
<b>E</b> 40			
F13	Integer	•	
		0	
		1	BREAKER EARTHED
		2	
		3	REMOTE TRIP
		4	BLOCK TRIP
		5	AUX1
		6	AUX2
		7	AUX3
		8	LOCKOUT (86)
		9	SET NEW DEMAND PERIOD
F14	16 Bits BitMan		Events Recorder Configuration Register Format
	то вно вницр	Bit 0	Ph. Protections Events $(0 - Off_{1} - On)$
		Bit 1	[A = On ]
		Bit 2	Volatore Protections Events { $0 - Off = 0 n$ }
			Frequency Protections Events $(0 - Off, 1 - On)$
			Power Protections Events $\{0 = 0H, 1 = 0h\}$
		DIL 4	[Fower From Content (0 - Off (1 - On))]
		DIL D	Output Polove Events $\{0 = OII, 1 = OII\}$
<u> </u>			Duput relays Events { $0 = 011$ , $1 = 011$ }
		BIL /	Digital inputs Events { U = OII , 1 = ON }
		BIt 8 ~ BIt 15	Not Used
F15	Integer		Output Relay Selection
		Bit 0	TRIP OUTPUT RELAY
		Bit 1	AUX.1 OUTPUT RELAY
		Bit 2	AUX.2 OUTPUT RELAY
		Bit 3	AUX.3 OUTPUT RELAY
F16	Integer		Protection Curve Definition Format
		0	DefiniteTime
		1	ANSI Moderate Inverse
		2	ANSI Normal Inverse
		3	ANSI Very Inverse
		4	ANSI Extrem Inverse
		5	IAC Moderate Inverse
		6	IAC Normal Inverse
		7	IAC Very Inverse
		8	IAC Extrem rInverse
		9	IEC ShortTime
		10	IEC A Normal Inverse
		11	IEC B Very Inverse
		12	IEC C Extrem Inverse
E17	Integer		BaudPate Definitions
117	integei	0	1200 Bps
		1	2400 Bps
		י ר	4800 Bps
		2	9600 Bre
		3	19200 Bps
		4	
F18	16 Bits BitMap		Led Status Register Format
		Dit O	TRIP LED:
		BILU	0 = "OFF", 1 = "ON"
		Di+ 1	AUX.1 LED:
		DILI	0 = "OFF", 1 = "ON"
		D# 0	AUX.2 LED:
		BIL 2	0 = "OFF", 1 = "ON"
		D# 0	AUX.3 LED:
		BIT 3	0 = "OFF", 1 = "ON"
			OUT OF SERVICE LED:
		Bit 4	0 = "OFF", 1 = "ON"
			Not Used
		BIt 5	
		D# 0	BREAKER OPEN LED:
		BILO	0 = "OFF", 1 = "ON"
		D# 7	BREAKER CLOSED LED:
		Bit /	0 = "OFF", 1 = "ON"
		<b>D</b> = 0	BREAKER EARTHED LED:
		Bit 8	BREAKER EARTHED LED: 0 = "OFF". 1 = "ON"
		Bit 8	BREAKER EARTHED LED: 0 = "OFF", 1 = "ON" AUTO-RECLOSE ENABLED LED:
		Bit 8 Bit 9	BREAKER EARTHED LED: 0 = "OFF", 1 = "ON" AUTO-RECLOSE ENABLED LED: 0 = "OFF", 1 = "ON"

		Bit 10	AUTO-RECLOSE IN PROGRESS LED:				
		Bit 10	0 = "OFF", 1 = "ON"				
		Bit 10	LOCKOUT LED: 0 - "OFF" 1 - "ON"				
			Not Used				
		BIL 12 ~ BIL 15					
E10	Integer		Power Easter Format				
F 19	integer						
F20	16 Bits BitMap	Dit a	Output Relays Status Register				
		Bit 0 Bit 1	I rip Output Relay { 0 = "Energized" , 1 = "De-energized" }				
		Bit 2	Aux2 Output Relay { 0 = "Energized" , 1 = "De-energized" }				
		Bit 3	Aux3 Output Relay { 0 = "Energized" , 1 = "De-energized" }				
		Bit 4 ~ Bit 15	Not Used				
F21	16 Bits BitMap		Digital Input Status Register				
		Bit 0	Digital Input 1 { 0 = "OPEN", 1 = "CLOSE" }				
		Bit 1 Bit 2	Digital Input 2 { 0 = "OPEN" , 1 = "CLOSE" }				
		Bit 3	Breaker Status Digital Input { 0 = "OPEN", 1 = "CLOSE" }				
		Bit 4 ~ Bit 15	Not Used				
F22	16 Bits BitMap		Status & Pickup Flags Format				
		Bit 0	Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON }				
		Bit 1	Phase Inst OverCurrent Protection { 0 = OFF , 1 = ON }				
		Bit 2 Bit 3	Phase OverCurrent Alarm Protection { 0 = OFF , 1 = ON }				
		Bit 4	Ground Inst OverCurrent Protection { 0 = OFF , 1 = ON }				
		Bit 5	Ground OverCurrent Alarm Protection { 0 = OFF , 1 = ON }				
		Bit 6	Not Used				
		Bit 7 Bit 8	Not Used				
		Bit 9	Not Used				
		Bit 10	Not Used				
		Bit 11	Not Used				
		Bit 12 Bit 13	Disconnector Block { U = OFF , 1 = ON } Breaker Driscrepancy Function { 0 = OFF , 1 = ON }				
		Bit 10	Mechanical Operations Function $\{0 - OFF, 1 - ON\}$				
		Dit 14					
		Bit 15	Accumulated Amp Function { 0 = OFF , 1 = ON }				
F23	Integer	Bit 15	Accumulated Amp Function { 0 = OFF , 1 = ON }				
F23	Integer	Bit 15	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command				
F23	Integer	0 1	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset				
F23	Integer	0 1 2	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip				
F23	Integer	0 1 2 5	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data				
F23	Integer	0 1 2 5	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data				
F23	Integer	0 1 2 5 8	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear Maintenance Data				
F23	Integer	0 1 2 5 8 9	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events				
F23	Integer	0 1 2 5 8 9 20	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1				
F23	Integer	0 1 2 5 8 9 20 21	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2				
F23	Integer	Bit 15           0           1           2           5           8           9           20           21           22	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux3				
F23	Integer	0 1 2 5 8 9 20 21 22	Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language				
F23	Integer	0 Bit 15 0 1 2 5 8 9 20 21 22 0	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used				
F23	Integer	Bit 15           0           1           2           5           8           9           20           21           22           0           1           2	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used English Detation				
F23	Integer	0 Bit 15 0 1 2 5 8 9 20 21 22 0 1 22 0 1 22	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used English Russian				
F23	Integer	0 Bit 15 0 1 2 5 8 9 20 21 22 0 1 22 0 1 22 0 1 22	Accumulated Amp Function { 0 = OFF , 1 = ON }         Accumulated Amp Function { 0 = OFF , 1 = ON }         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date & Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian				
F23	Integer Integer Integer Integer Integer Integer Integer Integer Integer	0 Bit 15 0 1 2 5 8 9 20 21 22 20 21 22 0 1 22 21 22 0 1 22 21 21	Accumulated Amp Function { 0 = OFF , 1 = ON }         Accumulated Amp Function { 0 = OFF , 1 = ON }         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date & Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status & Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON }				
F23	Integer Integer Integer Integer Integer Integer Integer Integer Integer	0 Bit 15 0 1 2 5 8 9 20 21 22 21 22 0 1 22 0 1 22 0 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 21 22 1 22 1 22 21 22 21 22 21 22 21 22 21 22 21 22 21 22 21 22 21 22 21 22 21 22 21 22 21 22 22	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used English Russian Status & Pickup Flags Format 1 Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase Inter OverCurrent Protection { 0 = OFF , 1 = ON } Negative Sequence Timed OverCurrent Protection { 0 = OFF , 1 = ON }				
F23	Integer Integer Integer Integer Integer Integer Integer Integer	0 Bit 15 0 1 2 5 8 9 20 21 22 0 1 22 0 1 22 0 1 22 0 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 22	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used English Russian Status & Pickup Flags Format 1 Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase Inst OverCurrent Protection { 0 = OFF , 1 = ON } Negative Sequence Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase OverCurrent Alarm Protection { 0 = OFF , 1 = ON } Phase OverCurrent Alarm Protection { 0 = OFF , 1 = ON }				
F23	Integer	0 0 1 2 5 8 9 20 21 22 0 1 22 0 1 22 0 1 22 0 1 22 0 1 22 1 2 3 1 3 1 3 Bit 1 Bit 3 Bit 4 3 Bit 4	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux3 Product Language Not Used English Russian Status & Pickup Flags Format 1 Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase Inst OverCurrent Protection { 0 = OFF , 1 = ON } Negative Sequence Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase OverCurrent Alarm Protection { 0 = OFF , 1 = ON } Amp. Unbalance Protection { 0 = OFF , 1 = ON }				
F23	Integer	0 0 1 2 5 8 9 20 21 22 20 21 22 0 1 22 0 1 22 0 1 22 1 22 1 22 1 22 1 22 1 22 22	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used English Russian Status & Pickup Flags Format 1 Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase Inst OverCurrent Protection { 0 = OFF , 1 = ON } Negative Sequence Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON }				
F23	Integer Intege	0 0 1 2 5 8 9 20 21 22 0 1 22 0 1 22 0 1 22 0 1 22 0 1 22 5 5 5 5 5 5 5 5 5 5 5 5 5	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used English Russian Status & Pickup Flags Format 1 Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase Inst OverCurrent Protection { 0 = OFF , 1 = ON } Negative Sequence Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Not Used Ground Timed OverCurrent Protection { 0 = OFF , 1 = ON }				
F23	Integer Intege	0 0 1 2 5 8 9 20 21 22 20 21 22 0 1 22 0 1 22 0 1 22 0 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 1 22 21 21	Accumulated Amp Function { 0 = OFF , 1 = ON }         Accumulated Amp Function { 0 = OFF , 1 = ON }         Command         Remote Reset         Remote Trip         Activate Date & Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status & Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Ground Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Ground Inst OverCurrent Protection { 0 = OFF , 1 = ON }				
F23	Integer Intege	0 0 1 2 5 8 9 20 21 22 21 22 0 1 22 0 1 22 0 1 22 0 1 22 1 21 2	Accumulated Amp Function { 0 = OFF, 1 = ON } Accumulated Amp Function { 0 = OFF, 1 = ON } Commands Operation Codes No Command Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used English Russian Status & Pickup Flags Format 1 Phase Timed OverCurrent Protection { 0 = OFF, 1 = ON } Phase Inst OverCurrent Protection { 0 = OFF, 1 = ON } Negative Sequence Timed OverCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase OverCurrent Protection { 0 = OFF, 1 = ON } Phase OverCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Phase UnderCurrent Protection { 0 = OFF, 1 = ON } Stround Inst OverCurrent Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = OFF, 1 = ON } Stround OverCurrent Alarm Protection { 0 = O				
F23	Integer Intege	0 0 1 2 5 8 9 20 21 22 21 22 0 1 22 0 1 22 0 1 22 0 1 22 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1 3 Bit 1 Bit 2 Bit 3 Bit 4 Bit 5 Bit 6 Bit 7 Bit 8 Bit 9 Bit 10 Bit 10	Accumulated Amp Function { 0 = OFF , 1 = ON } Accumulated Amp Function { 0 = OFF , 1 = ON } Commands Operation Codes No Command Remote Reset Remote Reset Remote Trip Activate Date & Time Preset Data Clear Maintenance Data Clear All Events Set Aux1 Set Aux2 Set Aux2 Set Aux3 Product Language Not Used English Russian Status & Pickup Flags Format 1 Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON } Phase Inst OverCurrent Protection { 0 = OFF , 1 = ON } Phase Inst OverCurrent Protection { 0 = OFF , 1 = ON } Phase Inst OverCurrent Protection { 0 = OFF , 1 = ON } Phase OverCurrent Protection { 0 = OFF , 1 = ON } Phase OverCurrent Protection { 0 = OFF , 1 = ON } Phase OverCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Phase UnderCurrent Protection { 0 = OFF , 1 = ON } Mot Used Ground Timed OverCurrent Protection { 0 = OFF , 1 = ON } Ground Inst OverCurrent Protection { 0 = OFF , 1 = ON } Not Used Ground OverCurrent Alarm Protection { 0 = OFF , 1 = ON } Not Used Brock Time OverCurrent Protection { 0 = OFF , 1 = ON } Not Used Brock Time OverCurrent Protection { 0 = OFF , 1 = ON } Not Used				
F23	Integer Intege	0 0 1 2 5 8 9 20 21 22 21 22 0 0 1 22 0 1 22 0 1 22 0 1 22 1 2 1 3 Bit 1 Bit 2 Bit 3 Bit 4 Bit 5 Bit 6 Bit 7 Bit 8 Bit 9 Bit 10 Bit 7 Bit 8 Bit 9 Bit 10 Bit 11 Bit 2 Bit 8 Bit 9 Bit 10 Bit 11 Bit 2 Bit 8 Bit 9 Bit 10 Bit 11 Bit 8 Bit 9 Bit 10 Bit 11 Bit 8 Bit 10 Bit 11 Bit 10 Bit 11 Bit 10 Bit 11 Bit 12 Bit 11 Bit 11 Bit 11 Bit 11 Bit 12 Bit 11 Bit 11 Bit 12 Bit 12 Bit 11 Bit 12 Bit 11 Bit 12 Bit 12 Bit 11 Bit 11 Bit 12 Bit 11 Bit 12 Bit 11 Bit 11	International operation of the control of the cont of the control of the control of the contro				
F23	Integer         Integer <td< th=""><th>Bit 15           0           1           2           5           8           9           20           21           22           0           1           2           8           9           20           21           22           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           1           1           1           2           1           1           1           2           1           2           3      <tr t=""> <th>Accumulated Amp Function { 0 = OFF , 1 = ON }         Accumulated Amp Function { 0 = OFF , 1 = ON }         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date &amp; Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status &amp; Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Not Used         Ground Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Not Used         Block Trip Out { 0 = OFF , 1 = ON }         Mot Used         Block Trip Out { 0 = OFF , 1 = ON }         Block Trip Out { 0 = OFF , 1 = ON }         Block Trip Out { 0 = OFF , 1 = ON }         Block King Ou</th></tr><tr><th>F23</th><th>Integer         Integer         <td< th=""><th>0 0 1 2 5 8 9 20 21 22 21 22 0 0 1 22 21 21</th><th>Intervention ( 0 = OFF, 1 = ON )         Accumulated Amp Function ( 0 = OFF, 1 = ON )         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date &amp; Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status &amp; Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase Sequence Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase OverCurrent Alarm Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Roround Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Stroud Dist OverCurrent Protection { 0 = OFF, 1 = ON }         Not Used       Ground Inst OverCurrent Protection { 0 = OFF, 1 = ON }         Block Trip Out { 0 = OFF, 1 = ON }       Encurve trip Out { 0 = OFF, 1 = ON }         Breaker Driscrepancy Function { 0 = OFF, 1 = ON }       Encurve treat Alarm Protection {</th></td<></th></tr></th></td<>	Bit 15           0           1           2           5           8           9           20           21           22           0           1           2           8           9           20           21           22           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           1           1           1           2           1           1           1           2           1           2           3 <tr t=""> <th>Accumulated Amp Function { 0 = OFF , 1 = ON }         Accumulated Amp Function { 0 = OFF , 1 = ON }         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date &amp; Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status &amp; Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Not Used         Ground Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Not Used         Block Trip Out { 0 = OFF , 1 = ON }         Mot Used         Block Trip Out { 0 = OFF , 1 = ON }         Block Trip Out { 0 = OFF , 1 = ON }         Block Trip Out { 0 = OFF , 1 = ON }         Block King Ou</th></tr> <tr><th>F23</th><th>Integer         Integer         <td< th=""><th>0 0 1 2 5 8 9 20 21 22 21 22 0 0 1 22 21 21</th><th>Intervention ( 0 = OFF, 1 = ON )         Accumulated Amp Function ( 0 = OFF, 1 = ON )         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date &amp; Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status &amp; Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase Sequence Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase OverCurrent Alarm Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Roround Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Stroud Dist OverCurrent Protection { 0 = OFF, 1 = ON }         Not Used       Ground Inst OverCurrent Protection { 0 = OFF, 1 = ON }         Block Trip Out { 0 = OFF, 1 = ON }       Encurve trip Out { 0 = OFF, 1 = ON }         Breaker Driscrepancy Function { 0 = OFF, 1 = ON }       Encurve treat Alarm Protection {</th></td<></th></tr>	Accumulated Amp Function { 0 = OFF , 1 = ON }         Accumulated Amp Function { 0 = OFF , 1 = ON }         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date & Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status & Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Not Used         Ground Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Not Used         Block Trip Out { 0 = OFF , 1 = ON }         Mot Used         Block Trip Out { 0 = OFF , 1 = ON }         Block Trip Out { 0 = OFF , 1 = ON }         Block Trip Out { 0 = OFF , 1 = ON }         Block King Ou	F23	Integer         Integer <td< th=""><th>0 0 1 2 5 8 9 20 21 22 21 22 0 0 1 22 21 21</th><th>Intervention ( 0 = OFF, 1 = ON )         Accumulated Amp Function ( 0 = OFF, 1 = ON )         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date &amp; Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status &amp; Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase Sequence Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase OverCurrent Alarm Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Roround Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Stroud Dist OverCurrent Protection { 0 = OFF, 1 = ON }         Not Used       Ground Inst OverCurrent Protection { 0 = OFF, 1 = ON }         Block Trip Out { 0 = OFF, 1 = ON }       Encurve trip Out { 0 = OFF, 1 = ON }         Breaker Driscrepancy Function { 0 = OFF, 1 = ON }       Encurve treat Alarm Protection {</th></td<>	0 0 1 2 5 8 9 20 21 22 21 22 0 0 1 22 21 21	Intervention ( 0 = OFF, 1 = ON )         Accumulated Amp Function ( 0 = OFF, 1 = ON )         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date & Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status & Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase Sequence Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase OverCurrent Alarm Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Roround Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Stroud Dist OverCurrent Protection { 0 = OFF, 1 = ON }         Not Used       Ground Inst OverCurrent Protection { 0 = OFF, 1 = ON }         Block Trip Out { 0 = OFF, 1 = ON }       Encurve trip Out { 0 = OFF, 1 = ON }         Breaker Driscrepancy Function { 0 = OFF, 1 = ON }       Encurve treat Alarm Protection {
Accumulated Amp Function { 0 = OFF , 1 = ON }         Accumulated Amp Function { 0 = OFF , 1 = ON }         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date & Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status & Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase OverCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Phase UnderCurrent Protection { 0 = OFF , 1 = ON }         Not Used         Ground Timed OverCurrent Protection { 0 = OFF , 1 = ON }         Not Used         Block Trip Out { 0 = OFF , 1 = ON }         Mot Used         Block Trip Out { 0 = OFF , 1 = ON }         Block Trip Out { 0 = OFF , 1 = ON }         Block Trip Out { 0 = OFF , 1 = ON }         Block King Ou							
F23	Integer         Integer <td< th=""><th>0 0 1 2 5 8 9 20 21 22 21 22 0 0 1 22 21 21</th><th>Intervention ( 0 = OFF, 1 = ON )         Accumulated Amp Function ( 0 = OFF, 1 = ON )         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date &amp; Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status &amp; Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase Sequence Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase OverCurrent Alarm Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Roround Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Stroud Dist OverCurrent Protection { 0 = OFF, 1 = ON }         Not Used       Ground Inst OverCurrent Protection { 0 = OFF, 1 = ON }         Block Trip Out { 0 = OFF, 1 = ON }       Encurve trip Out { 0 = OFF, 1 = ON }         Breaker Driscrepancy Function { 0 = OFF, 1 = ON }       Encurve treat Alarm Protection {</th></td<>	0 0 1 2 5 8 9 20 21 22 21 22 0 0 1 22 21 21	Intervention ( 0 = OFF, 1 = ON )         Accumulated Amp Function ( 0 = OFF, 1 = ON )         Commands Operation Codes         No Command         Remote Reset         Remote Trip         Activate Date & Time Preset Data         Clear Maintenance Data         Clear All Events         Set Aux1         Set Aux2         Set Aux3         Product Language         Not Used         English         Russian         Status & Pickup Flags Format 1         Phase Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase Sequence Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Phase OverCurrent Alarm Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Phase UnderCurrent Protection { 0 = OFF, 1 = ON }         Roround Timed OverCurrent Protection { 0 = OFF, 1 = ON }         Stroud Dist OverCurrent Protection { 0 = OFF, 1 = ON }         Not Used       Ground Inst OverCurrent Protection { 0 = OFF, 1 = ON }         Block Trip Out { 0 = OFF, 1 = ON }       Encurve trip Out { 0 = OFF, 1 = ON }         Breaker Driscrepancy Function { 0 = OFF, 1 = ON }       Encurve treat Alarm Protection {				

F26	16 Bits BitMap		Status & Pickup Flags Format 2
		Bit 0	UnderVoltage 1 Protection { 0 = OFF , 1 = ON }
		Bit 1	OverVoltage 1 Protection { 0 = OFF , 1 = ON }
		Bit 2	Not Used
		Bit 3	Not Used
		Bit 4	Phase Reversal Protection { 0 = OFF , 1 = ON }
		Bit 5	Frequency 1 Protection { 0 = OFF, 1 = ON }
		Bit 6	Frequency 2 Protection { 0 = OFF, 1 = ON }
		Bit 7	Not Used
		Bit 8	Not Used
		Bit 9	Power Factor Leading Protection { 0 = OFF , 1 = ON }
		Bit 10	Power Factor Lagging Protection { 0 = OFF , 1 = ON }
		Bit 11	Reverse Power Protection { 0 = OFF , 1 = ON }
		Bit 12	Forward Power Protection { 0 = OFF, 1 = ON }
		Bit 13	Amps Demand Protection { 0 = OFF, 1 = ON }
		Bit 14	KW Demand Protection { 0 = OFF, 1 = ON }
		Bit 15	Kvar Demand Protection { 0 = OFF, 1 = ON }
F27	16 Bits BitMap		Status & Pickup Flags Format 3
	•	Bit 0	Not Used
		Bit 1	Not Used
		Bit 2	Not Used
		Bit 3	Not Used
		Bit 4	Not Used
		Bit 5	Not Used
		Bit 6	Not Used
		Bit 7	Not Used
		Bit 8	Not Used
		Bit 9	Not Used
		Bit 10	Not Used
		Bit 11	Not Used
		Bit 12	Not Used
		Bit 13	Not Used
		Bit 14	Not Used
		Bit 15	Not Used
F28	Integer		Not Used
F29	Integer		Protection Curve Definition Format
		0	DefiniteTime
		1	Inverse
F30	Integer		Phases for Protection Operation
		0	Any One
		1	Any Two
		2	All Three
F31	Integer		Frequency Protection Mode
		0	O/F + U/F
		1	O/F
		2	U/F
F32	Integer		Phase Sequence
		0	None
		1	A-B-C
		2	A-C-B

	SMPR-1 Event Cause List :
0	No Event
1	Events Clear
4	Trip Relay OFF
5	Trip Relay ON
6	Aux.1 Relay OFF
7	Aux.1 Relay ON
8	Aux.2 Relay OFF
9	
10	Aux 3 Relay OFF
- 11	Aux.s Relay ON
20	Digital Input 1 Deactive
20	Digital Input 1 Active
22	Digital Input 2 Deactive
23	Digital Input 2 Active
24	Digital Input 3 Deactive
25	Digital Input 3 Active
26	Breaker Status "OPENED"
27	Breaker Status "CLOSED"
32	Earth Released
33	Breaker Earthed
34	Remote Trip
35	Serial Comunication Trip
36	Block Trip Reset
31	Block The Set
40	Proglar Discrongnay Alarm
40	Mechanical Operation Alarm
42	Accumulated Amp Alarm
43	Maintenance Data Clear
50	Phase Timed OverCurrent
51	Phase Inst OverCurrent
52	Phase OverCurrent Alarm
53	Amp. Unbalance
54	Phase UnderCurrent
55	Reserved
56	Negative Sequence Timed O/C
60	Ground Timed OverCurrent
62	
02	
70	InderVoltage 1
71	OverVoltage 1
72	Reserved
73	Reserved
74	Phase Reversal
80	Frequency 1
81	Frequency 2
90	Power Factor Leading
91	Power Factor Lagging
92	Reverse Power
93	Forward Power
94	Amps Demand
95	Kvor Demand
90	